



- To set low gain offset:
1. Close TP1 & TP2
  2. Turn R10 all the way down
  3. Adjust R10 for Pin6=0.0 VDC
  4. Open TP1 & TP2
  5. Adjust gain to max for Servo recover

Gain	R48	R481
0 dB	1k	none
6 dB	2k	2k (Truck)
12 dB	4k02	1k33
15 dB	5k6	1k21 (Doppler)

From original build:  
 Change R41 to 5k11  
 Change R34 to 2k  
 Change R35 to 2k  
 Change R49 to 2k  
 Add R481, 2k

S1